



HCB Auto Tools

Hwang Cherng Bin Specialty Tools Inc. (HCB)

Browse

[JAPANESE TRUCK REPAIR TOOLS](#)



H.C.B-A2018 MITSUBISHI CANTER 3.5 TONS OIL FILTER WRENCH (Dr. 1/2", 15 POINTS, 100mm)

* To remove oil filter. * Application: Mitsubishi Canter 3.5 tons/FUSO * Size: Dr. 1/2", 15 points, 100mm *
Genuine no.: ME013343 [\[Product Details...\]](#)



H.C.B-A2018-1 MITSUBISHI NEW CANTER 8.8 TONS OIL FILTER WRENCH (TURBO) (Dr. 1/2", 15 POINTS, 100mm)

* To remove oil filter * Application :Mitsubishi New Canter 8.8 tons. * Size :Dr. 1/2"™™, 15 points, 100mm
* Genuine No.: ME013307 [\[Product Details...\]](#)



H.C.B-A2018-2 HINO 15 TONS OIL FILTER WRENCH (Dr. 1/2", 16 POINTS, 108 mm)

*SIZE: Dr. 1/2", 16 POINTS, 108 mm *Applicable: HINO 15 tons before 2006. [\[Product Details...\]](#)



H.C.B-A2018-5 ISUZU OIL FILTER WRENCH (Dr. 1/2", 15 POINTS, 89mm)

* Size:Dr. 1/2", 15 points, 89mm * Well-designed tool to save time. [\[Product Details...\]](#)



H.C.B-A2018-11 FUSO NEW CANTER 3.5/11 TONS (EURO 4) DIESEL FILTER WRENCH (Dr. 1/2", 109 mm)

* Application: FUSO NEW CANTER 3.5/11 TONS (EURO 4). * To loosen fuel filter and drain oil out. * Before tighten filter, be sure to clean the surface and the trench of o-ring on the filter base carefully. * Size: Dr. 1/2", 8 ribs, 109mm [\[Product Details...\]](#)



H.C.B-A2018-12 MITSUBISHI ALL NEW CENTER DIESEL OIL AND WATER SENSOR WRENCH (12 POINTS, 54mm)

* Applicable: Mitsubishi all New Canter Euro 4, 3.5 tons, 6.7 tons and 6.9 tons. [\[Product Details...\]](#)



H.C.B-A2018-13 ISUZU/ HINO 17 TONS OIL FILTER WRENCH (EURO 4) (Dr. 1/2", 16 POINTS, 118 mm)

*Size:Dr. 1/2", 16 POINTS, 118 mm *N.W.:0.6 KGS [\[Product Details...\]](#)



MITSUBISHI CANTER DIESEL OIL FILTER REMOVER/ INSTALLER

*This tool set include H.C.B-2130-1 diesel oil filter wrench x1 and H.C.B-2130-2 diesel oil filter switch wrench x1 *Applicable: MITSUBISHI CANTER and most of diesel engine [\[Product Details...\]](#)



TRUCK TORQUE-ROD BUSH REMOVAL/ INSTALLATION PAT. M307531

* Put Torque-Rod into the main body with necessary accessories. * Stepping on the foot plate of air pump until the bush comes out. [\[Product Details...\]](#)



PITMAN ARM PULLER (Dr. 3/4", 62 mm)

* Applicable 15 tons ~35 tons of HINO, ISUZU, NISSAN, FUSO truck and bus [\[Product Details...\]](#)



PITMAN ARM PULLER (Dr. 3/4", 47mm)

* Applicable: HINO, ISUZU, NISSAN, FUSO, 8.8 tons ~ 10.5 tons truck * Time and labor saver, different from traditional type. To prevent pitman arm from damaged. [\[Product Details...\]](#)



UNIVERSAL AXLE EXTRACTOR (FOR TRUCKS ONLY)

* N.W.:7.5 kgs * Specification: .259 x 32mm * Screw specification: .30 x 6W * Applicable: Japanese truck only. Ex: HINO, UD truck 180 pulley. [\[Product Details...\]](#)



MITSUBISHI DELICA (2500 c.c.) WHEEL NUT REMOVER(Dr. 1/2")

*To remove the wheel nut *Applicable: MITSUBISHI DELICA 2500c.c [\[Product Details...\]](#)



FUSO STEERING MECHANISM OIL SEAL SOCKET (Dr. 1/2")

* While replaces steering mechanism oil seal, to regulate the nut with this tool and prevent nut from damaged. * Applicable: most of Japanese truck. (ex. FUSO) [\[Product Details...\]](#)



H.C.B-A1184 HINO CRANKSHAFT REAR OIL SEAL INSTALLER (JO8C/ JO8E)

* This tool is designed to prevent oil seal from damaged when installing it. * Application: HINO truck 10.5 tons /15 tons / 17 tons ; (JO8C/JO8E) Euro 3/5. * Oil seal genuine no.: AZ4079-F [\[Product Details...\]](#)



ISUZU CRANKSHAFT REAR OIL SEAL INSTALLER (3.5 TONS)

* This tool is specially designed for prevent the oil seal from damaged when installing it. * Oil seal genuine no.: BZ4962-E, 3-97071561 * Applicable : ISUZU 3.5 tons (4JB1, 4JG2,4JH1) (130HP/150HP) [\[Product Details...\]](#)



H.C.B-A1127 FUSO REAR WHEEL NUT SOCKET (8 POINTS, 120 mm)

*Fixed bearing in the right position while removing/installing the truck nut. *Regulating the nut with slide rod to adjust the tightness of bearing. [\[Product Details...\]](#)



ISUZU CRANKSHAFT OIL SEAL REPLACER

* The best tool for replacing crankshaft oil seal. * No damage to oil seal and related parts. * Easy to use. Helps to install the oil seals accurately. Save time and money. * Applicable: ISUZU truck. Engine Model: 4 HF1,4HG1,6HH1,6HK1 * Oil Seal genuine [\[Product Details...\]](#)



mitsubishi center axle ball joint puller

* Special design. Easy to use. The hooks are adjustable, suited to different ball joints. * For MITSUBISHI CANTER front wheel axle ball joint. * Applicable: MITSUBISHI CANTER 3.5 tons, 4.4 tons and Fuso Rosa.

[\[Product Details...\]](#)



HINO STEERING MECHANISM OIL SEAL SOCKET(Dr. 1/2")

*To loose / tighten the nut, when replaces steering mechanism oil seal. It could be caused damage without use this tool while replacing oil seal. *Applicable: For HINO truck use only. After 1994, 21~35 tons truck.

[\[Product Details...\]](#)



H.C.B-A1275 HINO / ISUZU / FUSO / UD ANCHOR PIN REMOVER (HYDRAULIC)

[\[Product Details...\]](#)



HINO 11.9 TONS REAR WHEEL AXLE NUT SOCKET (Dr. 3/4" , 8 POINTS, 105mm)

*Apply to HINO 11.9 tons truck rear wheel axle nut removal/ installation. *Size: Dr.3/4" , 8 points, 105mm

[\[Product Details...\]](#)



HINO CRANKSHAFT FRONT OIL SEAL INSTALLER

*This tool is designed for prevent the HINO crankshaft front oil seal from damaged when installing it. *
Applicable HINO truck PROFIA K13C-TE 350P 700 series E13C 420P. * Oil seal genuine no.: AH3618-M,
BZ5376E [\[Product Details...\]](#)



H.C.B-A2018-17 FUSO TRUCK (6.5 / 6.8 / 7.7 TONS) OIL FILTER WRENCH (Dr. 1/2", 16 POINTS, 106.5mm)

*Applicable: FUSO 6.5 / 6.8 / 7.7 tons truck [\[Product Details...\]](#)



H.C.B-A2018-18 FUSO TRUCK (10.5 ~ 17 TONS) OIL FILTER WRENCH (15 POINTS, 119mm)

*Genuine No. ME 074013 *Applicable: FUSO 10.5 ~ 17 tons truck [\[Product Details...\]](#)



ISUZU, FUSO, TOYOTA SPRING PIN METAL BUSH REMOVE / INSTALL SET (HYDRAULIC)

[\[Product Details...\]](#)



TRUCK VALVE REMOVER / INSTALLER

* To remove and install the valve of truck * Applicable: FUSO 3.5 tons, FUSO over 15 tons, HINO 750, ISUZU 180, ISUZU 200 and VOLVO FM truck. [\[Product Details...\]](#)



H.C.B-A1351 UD 350 (CK450)/ UD 380 (CK451) TRUCK CRANKSHAFT REAR OIL SEAL INSTALLER

[\[Product Details...\]](#)



H.C.B-A2018-21 HINO TRUCK/ISUZU (3.5 TONS) (EURO 4/ NL EURO 5) OIL MIST SEPARATOR WRENCH (Dr. 1/2", 8 RIBS, 107mm)

[\[Product Details...\]](#)



H.C.B-A2018-20 FUSO OIL MIST SEPARATOR WRENCH(Dr.1/2",8 RIBS, 109mm)

[\[Product Details...\]](#)